

# Chapter 27 - Walkways, Driveway, and Parking Pad

## Contents

Chapter 27 - Walkways, Driveway, and Parking Pad..... 27-1

***Critical Issues***

- Ensure the conductor lines have been installed under the forms for the sidewalks before the concrete is poured.

***Safety Issues***

- Ensure the tops of all metal stakes are covered with plastic caps.

## Timing & Prerequisites

- The conductor lines must be installed before the concrete sidewalks. If the conductor lines are not installed in time, the contractor will place pieces of pipe under the walk before they pour them. The ends of the pipe should be marked with a stake.
- All work involving heavy equipment and trucks must be completed before pouring the flat concrete.

The contractor hired by Habitat will form-up the steps, walks, and driveway / parking pad. They will then pour all of the flat concrete.